








Image	Code Ending	Configuration	Seats	O Extra Natural- Organic	V Extra Natural- Vernon	Z Natural
 AC	<b>1</b>	ARMCHAIR	<b>1</b>			
	<i>CM</i> w x d x h	<b>114x94x83</b>				
 2S	<b>2</b>	2 SEATER	<b>2</b>			
	<i>CM</i> w x d x h	<b>176x94x83</b>				
 3S	<b>3</b>	3 SEATER	<b>3</b>			
	<i>CM</i> w x d x h	<b>232x94x83</b>				
 2.5S	<b>4</b>	2.5 SEATER	<b>3</b>			
	<i>CM</i> w x d x h	<b>212x94x83</b>				
 OTTO	<b>D</b>	OTTOMAN	<b>1</b>			
	<i>CM</i> w x d x h	<b>82x60x41</b>				
 2RAF	<b>X</b>	2SRAF	<b>2</b>			
	<i>CM</i> w x d x h	<b>150x94x83</b>				
 2LAF	<b>XA</b>	2SLAF	<b>2</b>			
	<i>CM</i> w x d x h	<b>150x94x83</b>				

Please Note: Dimensions quoted on this document are approximate and may vary slightly from the actual product  
All diagrams on the sheet are only provided as an approximate representation of the footprint of the lounge and are in no way intended to represent the actual shape of the lounge.

**Model Name: REMI**

**Construction**

**Additional Comments**

COVER TYPE: LEATHER  
COVER DESCRIPTION & OPTIONS:  
CAT O = Extra Natural Leather (Organic)  
CAT V = Extra Natural Leather (Vernon)  
CAT Z = Natural Leather  
SEAT: No-sag Spring + Inner Coil  
SEAT CUSHION: Foam D/38S + D/29 + Inner Coil  
BACK REST: Rubber Webbing  
BACK REST CUSHION: 100% Loose Fiber  
FRAME: Hardwood  
LEGS: Timber

**IMPORTANT:**

- This model has a very natural leather which markings such as grain variation, wrinkles skin folds, scars or patterns of original hair follicles are inherent in leather, they are not quality defects. (Examples as showing in the photos below)
- Accidental Warranty and Care products are not to be sold or used on this lounge.

**CARE INSTRUCTION:**

- Avoid placing your sofa in direct sunlight or under intense indoor light.
- Dust regularly using a soft, dry and white cloth.
- Do not use solvents or abrasive liquids as they will cause damage to surface and discoloration.
- Blot spills immediately with a dry, clean and white adsorbent cloth and allow it to dry naturally.
- Do not blow dry using a hot air dryer.

