

Image	Code Ending	Configuration	Seats	A ANCONA	C CHARLOTTE	N FLANIGAN	S SUNDAY
	++	SQUARE CORNER	2				
	CM w x d x h	117x117x80					
	ARW	** LAF-CHAISE+ CONSOLE + 1.25NA + C + 1.25NA + 1.25-RAF-ER	8				
	CM w x d x h	333x302x80-101					
	AWA	** 1.25-LAF-ER + 1.25NA + 1.25NA + CORNER + CONSOLE + RAF-CHAISE	8				
	CM w x d x h	333x302x80-101					
	CS	CONSOLE IN LOUNGE	1				
	CM w x d x h	32x107x80					
	E	ARMLESS CHAIR	1				
	CM w x d x h	62x107x80-101					
	EB	** BATTERY-ELECTRIC RECLINER CHAIR	1				
	CM w x d x h	106x107-161x80-101					
	EGB	** 1.25LAF BATTERY ELEC	1				
	CM w x d x h	103x107-161x80-101					
	EGE	** 1.25LAF RC ELE	1				
	CM w x d x h	103x107-161x80-101					
	EHB	** 1.25RAF BATTERY ELEC	1				
	CM w x d x h	103x107-161x80-101					
	EHE	** 1.25RAF RC ELE	1				
	CM w x d x h	103x107-161x80-101					
	EMB	** ARMLESS CHAIR BAT-ELE	1				
	CM w x d x h	62x107-161x80-101					
	EME	** 1 ARMLESS ELECTRIC RECLINER	1				
	CM w x d x h	62x107-161x80-101					

Please Note: Dimensions quoted on this document are approximate and may vary slightly from the actual product
All diagrams on the sheet are only provided as an approximate representation of the footprint of the lounge and are in no way intended to represent the actual shape of the lounge.

** Electric recliners require 240v mains power

Image	Code Ending	Configuration	Seats	A ANCONA	C CHARLOTTE	N FLANIGAN	S SUNDAY
 1.25NA	EQ	1.25 SEAT ARMLESS CHAIR	1				
	CM w x d x h	81x107x80-101					
 1.25NA-BATT-RC	EQB	** 1.25 ARMLESS BAT-ELE	1				
	CM w x d x h	81x107-161x80-101					
 1RAF-ELE-RC	EQC	** 1RAF RC ELEC	1				
	CM w x d x h	84x107-161x80-101					
 1LAF-ELE-RC	EQD	** 1LAF RC ELEC	1				
	CM w x d x h	84x107-161x80-101					
 1.25NA-ER	EQE	** 1.25 SEAT ARMLESS MOT-ELEC	1				
	CM w x d x h	81x107-161x80-101					
 ELECTRIC-RC	ER	** ELECTRIC RECLINER CHAIR	1				
	CM w x d x h	106x107-161x80-101					
 1.25ER+CON+1.25+C+1.25NA+1.25ER	GHE	** 1.25ELE LAFRC+CONSOLE +1.25NA +C +1.25NA +1.25ELE RAFRC	8				
	CM w x d x h	333x302x80-101					
 1RAFRC-BATT-ELE	QCB	** 1RAF BATTERY ELECTRIC	1				
	CM w x d x h	84x107-161x80-101					
 1LAFRC-BATT-ELE	QDB	** 1LAF BATTERY ELECTRIC	1				
	CM w x d x h	84x107-161x80-101					
 CHLAF	W	CHAISE LAF	2				
	CM w x d x h	103x173x80-101					
 CHRAF	WA	CHAISE RAF	2				
	CM w x d x h	103x173x80-101					

Please Note: Dimensions quoted on this document are approximate and may vary slightly from the actual product
All diagrams on the sheet are only provided as an approximate representation of the footprint of the lounge and are in no way intended to represent the actual shape of the lounge.

** Electric recliners require 240v mains power

Model Name: TAZIO

Construction

Additional Comments

COVER TYPE: FABRIC
 COVER DESCRIPTION:
 CAT S = Sunday Fabric
 CAT N = Flanigan Fabric
 CAT A = Ancona Fabric
 FRAME: Hardwood Frame
 BACK CUSHION: High Density Foam + Polyester Fiber
 SEAT CUSHION: High Density Foam + Polyester Fiber
 BASE SUSPENSION: Webbing + Spring
 BACK SUSPENSION: Webbing

GROUP COMBINATION:
ARW = LAF-CH+CS+1.25+C+1.25+1.25ER = W + CS + EQ + (++) + EQ + EHE
AWA = 1.25ER+1.25+C+1.25+CS+RAF-CHAISE = EGE + EQ + (++) + EQ + CS + WA
GHE = 1.25LAF-ELE-RC+CON+1.25+C+1.25+1.25RAF-ELE-RC = EGE + CS + EQ + (++) + EQ + EHE

PLEASE NOTE:
THIS RECLINER RANGE HAS A CHILD SAFETY LOCK FEATURE - tiny circular button in the middle of recliner button, which needs a pin-like stick to activate.
The corner Headrest and the console head rest is fixed.

BATTERY-OPERATED RECLINER OPTIONS
EGB (L) / EHB (R) = 1.25S 1 ARM (1MOT)-BATT-ELEC
EQB = 1.25 ARMLESS (1MOT)-BATT-ELEC
QDB (L) / QCB (R) = 1S 1 ARM (1MOT)-BATT-ELEC
EMB = 1S ARMLESS (1MOT)-BATT-ELEC
EB = BATT-ELEC RECLINER
 IF CUSTOMER WANTS BATTERY-OPERATED VERSION - ORDER MUST SPECIFY AND USE BATTERY CODE.

Battery IMPORTANT information:

- 1) The battery pack needs to be charged initially for 12 hours before use.
- 2) You **MUST** charge it every 4 weeks otherwise the battery life will fail. User must never let unit fully discharge as this shortens the life of the battery pack.
- 3) Battery pack is warranted for one year - replacement battery packs are available for purchase if required.
- 4) If the light is orange, this means it's fully charged.
- 5) If light is red, this means the battery pack needs recharging
- 6) No light means battery pack is discharged and requires charging
- 7) If going away on an extended holiday, user should switch off at the back, just by pushing it off and then back on when home again

MAXIMUM WEIGHT RATING FOR SINGLE RECLINER IS 150KG.